

## ROUSH Trunk Mounted Tool Box Kit

Kit Part Number 1310R08030006

Application: 2010-11 Ford Mustang GT

### Installation Instructions

Before installing your ROUSH Performance Product(s), read through the entire installation procedure and check to make sure all items are present. Contact ROUSH Customer Service at 1-800-59-ROUSH, 9:00 AM to 5:00 PM EST, weekdays, for any questions regarding fit, missing parts or instructions that are unclear to you.



Note: The extra slot in the tool kit bottom foam liner is for your wheel lock key.

# ROUSH

THE ART OF PERFORMANCE ENGINEERING®



**ROUSH Tool Kit Includes:**

- Mechanics Gloves
- 8 mm Combination Wrench
- 3/8" Combination Wrench
- 10 mm Combination Wrench
- 13 mm Combination Wrench
- 3/8" Drive Ratchet
- 14 mm Socket - 3/8" Drive
- 13 mm Socket - 3/8" Drive
- 11 mm Socket - 3/8" Drive
- 10 mm Socket - 3/8" Drive
- Mini Maglite® (2-AA) Flash Light
- 0-60 psi Tire Pressure Gauge
- Screw Driver w/ 6 various tips
- Needle Nose Pliers - 8"
- Channel Lock Pliers - 10"
- Tire Tread Depth Gauge
- Decorative ROUSH Medalion
- Additional slot for Wheel Lock Key

## Packaging List for ROUSH Tool Kit

Part Description	ROUSH Part Number	Qty
<b>Trunk Mounted Tool Box Kit</b>	<b>1310R08030006</b>	<b>1</b>
Trunk Tool Box	R08030007	1
<b>Hardware Kit - Trunk Tool Box</b>	<b>1305-R08030009</b>	<b>1</b>
Adapter Bracket Assy (plastic w/ nut)	R08030008	2
Bolt - 1/4"-20 Allen head cap		2
Washer - 1/4" Fender		2
<b>Hardware Kit - Trunk Tool Box Mounting Kit</b>	<b>1310R08030006HK</b>	<b>1</b>
Mounting Bracket LH	R08030029	1
Mounting Bracket RH	R08030030	1
Screw - Self-drilling / tapping #8 TEK	R07030003	6
Double sided tape - 1/2" x 3/4"	131008030010	1
Template - Bracket Positioning ***	1310R08030006TPA	1
Template - Deck Lid Liner Cutting ***	1310R08030006TPB	1
Installation Instructions	1310R08030006IM	1

\*\*\* Not shown

## Equipment and Supplies Required

- Push Pin removing tool
- Knife to cut Inner Trunk Liner
- Center Punch & Hammer or a Self Impacting Center Punch
- Drill with 1/4" Drive Adapter
- 1/4" Socket - 1/4" drive
- 3/16" Allen Wrench or 1/4 Drive Allen Socket

- Masking Tape
- Scissors
- Small Screw Driver



## **LIMIT OF LIABILITY STATEMENT**

The information contained in this publication was accurate and in effect at the time the publication was approved for printing and is subject to change without notice or liability. ROUSH Performance Products (RPP) reserves the right to revise the information presented herein or to discontinue the production of parts described at any time.

## **SAFETY REQUIREMENTS**

**STOP! READ IMPORTANT SAFETY CAUTIONS AND WARNINGS BEFORE PROCEEDING.**

### **IMPORTANT SAFETY NOTICE**

Appropriate disassembly, assembly methods and procedures are essential to ensure the personal safety of the individual performing the kit installation. Improper installation due to the failure to correctly follow these instructions could cause personal injury or death. Read each step of the installation manual carefully before starting the actual installation.

1. Always wear safety glasses for eye protection.
2. Place ignition switch in the OFF position.
3. Always apply the parking brake when working on a vehicle.
4. Chock the front and rear tires to prevent unexpected vehicle movement.
5. If working without a lift, always consult vehicle manual for correct lifting specifications.
6. Operate the engine only in well-ventilated areas to avoid exposure to carbon monoxide.
7. Do not smoke or use flammable items near or around the fuel system.
8. Use chemicals and cleaners in well-ventilated areas.
9. Batteries produce explosive gases, which can cause personal injury. Therefore, do not allow flames, sparks or flammable substances to come near the battery.
10. Keeps hands and any other objects away from the radiator fan blades.
11. Keep yourself and your clothing away from moving parts when the engine is running.
12. Do not wear loose clothing or jewelry that can get caught in rotating parts or scratch surface finishes.
13. Allow the engine, cooling system, brakes and exhaust to cool before working on a vehicle.

### **WORK SAFELY!**

Perform this installation on a good clean level surface for maximum safety and with the engine turned off.

# ROUSH

THE ART OF PERFORMANCE ENGINEERING®

1. Open the trunk and remove thirteen (13) push pins indicated with circles. Refer to Figure 1. The push pins are a two (2) part push pin. Remove the center button first to release the barbs and then remove the push pin body. Carefully slide the glow-in-the-dark trunk release handle through the slot in the trunk liner. See arrow. Remove the trunk inner liner.



Figure 1


2. Vehicles equipped with a satellite antenna, remove the connector push pin from the holes in the trunk inner structure. With a small screw driver, remove the push pin retainer from the connector. Refer to Figure 2. Push the release tab and unplug the connectors.



Figure 2



3. Retrieve the Bracket Positioning Template from the kit. Fold the template on the dotted line. Align the shaded holes on the template to the corresponding holes on the trunk lid inner structure. Tape the template in place. Refer to Figures 3.



Figures 3

4. Center punch the top four (4) bracket mounting points as shown on the template. Refer to Figure 4. Remove the paper template.




Figure 4

**Note:** Before installing the Self-drilling Screws, set your drill to a light setting to avoid stripping the holes or breaking the screws.



Figure 5

5. Position the Left Side Bracket to the left two (2) center punch points. Install the top two (2) Self-drilling Screws to secure the Bracket top to the deck lid inner structure. Refer to Figure 5.

6. Gently pull the lower part of the mounting bracket rearward (3-4 mm) and place a plastic Adapter Bracket into the slot. Ensure that the nut is on the back side of the bracket. Refer to Figures 6. Install a Self-drilling Screw through the bottom hole of the bracket into the trunk inner structure.



Figures 6

7. Repeat Steps 5 for the right side bracket. ( Top two (2) screws only )

8. Pass the wire harness end of the satellite antenna connector behind the right mounting bracket and reconnect the connectors. Peel the backing tape from the Double Sided Tape and affix the connector to the trunk inner structure as shown. Refer to Figure 7.

**Note:** Do not put the connector into its original position. Installation of the tool box will crush the connector.



Figure 7

9. Repeat Steps 6 for the right side bracket. ( Adapter Bracket and bottom screw )
10. Torque the six (6) Screws to 20-22 In-Lb.

11. Retrieve the Deck Lid Liner Cutting Template from the kit. Cut out the three (3) sections shown on the template. Position the Deck Lid Liner Cutting Template onto the deck lid liner with the raised portions of the liner in the template cut outs. Refer to Figure 8. Cut out the two (2) 1/2" square holes in the deck lid liner as indicated on the template. Remove the cutting template.




Figure 8

12. Reinstall the trunk inner liner and 13 push pins. Ensure that you pass the glow-in-the-dark trunk release handle through the slot in the trunk liner. Refer to Figure 9 and Figure 1. Ensure the 1/2" holes in the liner expose the Adapter Bracket nuts.




Figure 9



13. Open the Tool Kit and remove the ROUSH mechanics gloves. With an assistant, raise the opened ROUSH Tool Box to align the slots in the Tool Box Lid to the nuts in the plastic Adapter Brackets. Install the two (2) Washers and Bolts to fasten the Tool Box Lid to the Plastic Adapter Brackets. Refer to Figure 10.




Figure 10

14. Replace the ROUSH Mechanics Gloves back into the tool kit. Close and latch the ROUSH Tool Kit.



**Congratulations!!!** You have completed the installation of the ROUSH Performance Products, Trunk Mounted Tool Kit. It is recommended that you save all parts removed from your vehicle during the installation of this kit.





## WARRANTY

All retail parts carry a 90-day warranty from the date of purchase. This warranty covers defects in materials or workmanship, and does not include (i) normal wear and tear, environmental conditions, improper installation; (ii) road hazards, misuse, abuse, neglect, accidents, collision, fire, theft, freezing, vandalism, riot, explosion, or objects striking the vehicle; (iii) misusing the vehicle, such as driving over curbs, overloading, racing, or using the vehicle as a stationary power source; (iv) altering, disassembling or modifying the parts; (v) defects caused or induced by failures, breakdowns, or damage by other parts, components or the vehicle; (vi) subjecting the parts to excessive moisture or water or any motor vehicle fluids (e.g.: oil, anti-freeze, battery acid, brake fluid, etc.); (vii) acts of God, natural disasters and other similar causes beyond the reasonable control of ROUSH; or (viii) application of chemicals that affect the parts. This Limited Warranty does not cover surface deterioration of paint, trim, and appearance items that result from use and/or exposure to the elements, such as stone chips, scratches, bird droppings, lightning, hail, windstorm, dings, dents, earthquake, road salt, tree sap, water or flood.

ROUSH SHALL NOT BE LIABLE TO REIMBURSE CUSTOMER/DEALER FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE INSTALLATION OR USE OF ANY PRODUCT SOLD THROUGH THIS CATALOG OR ARISING OUT OF ANY BREACH OF WARRANTY. EXCEPT AS MAY BE STATED IN THIS CATALOG, ROUSH DISCLAIMS ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ROUSH'S LIABILITY EXCEED THE PRICE PAID BY CUSTOMER/DEALER FOR PRODUCTS SOLD REGARDLESS IF ROUSH HAS BEEN ADVISED IN ADVANCE OF ANY POTENTIAL PROBLEM OR IF A CLAIM IS BASED ON CONTRACT, TORT, STRICT LIABILITY, PRODUCT LIABILITY OR OTHERWISE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF IMPLIED WARRANTIES OR THEIR DURATION, OR LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSIONS OR LIMITATIONS MAY NOT APPLY.